



SOUNDTOUCH[®] 300

universal remote control

SETUP GUIDE • GUÍA DE CONFIGURACIÓN • GUIDE D'INSTALLATION

CONTENTS

Programming the Universal Remote Control 3

Using the Remote Control

Universal remote control buttons 4

Source selection 4

***Bluetooth*[®] Technology**

Pairing a mobile device 5

Pairing a mobile device with NFC 5

Universal Remote Control Device Codes

TV 6

Cable 8

Satellite 10




DVD 11

CD 13

VCR 13

Audio Accessory 14





Video Accessory 14

The universal remote control has four programmable source buttons (, **AUX**,  and ). You can program these buttons to control your TV, cable/satellite box, DVD or Blu-ray Disc™ player, game system, DVR or other auxiliary source by entering the code for your source's brand. There may be several codes for your source. You may need to perform this procedure multiple times to locate the correct code.

Locate the code

1. Power on your source.
2. Locate the code for your source's brand in the appropriate section of the Universal Remote Control Device Codes list (located in the back of the guide).

Enter the code

1. On the remote control, press and hold the appropriate source button (, **AUX**,  or ) until all six source buttons glow, then release. For example, to program your TV, press and hold  until all six source buttons glow, then release.

The appropriate source button continues to glow.


2. On the number keypad, enter the code for your source's brand and press **vol.**

Test the code

1. Test the source for basic functions by following the instructions for your source:
 - **TV**: press the channel buttons. Press **MENU**. The settings menu appears. Press **◀** and **▶** to navigate.
 - **Cable/satellite box**: press **GUIDE**. The programming guide appears. Press **◀** and **▶** to navigate.
 - **DVD or Blu-ray Disc™ player**: press **GUIDE**. The settings menu appears. Press **◀** and **▶** to navigate.
 - **Game system**: press **◀** and **▶** to navigate through the menu.
2. Based on your source's response to basic functions:
 - **Remote responds accurately**: press **EXIT** to exit programming and save your settings.
 - **Remote does not respond or does not respond accurately**:
 - **If your source button glows**: press **vol.** to move to the next code. Repeat steps 1 and 2 in "Test the code." You may need to repeat this procedure 30 or more times. If all six buttons blink three times, you have cycled through all codes for your source.
 - **If your source button is off**: your remote exited programming mode. Repeat steps 1 and 2 in "Enter the code" and steps 1 and 2 in "Test the code."

Note: Your source may not be compatible with universal remote controls or may not accept IR (infrared) signals. Refer to your source owner's guide for more information.

Universal remote control buttons



Source selection

After programming the remote control, you can switch between sources by selecting different inputs on your TV using the remote control.

Notes:



- To use the *Bluetooth*® source, you must pair a mobile device to the soundbar (see page 5).
- Pressing , **AUX**, or on the remote control does not switch the source. It turns on the soundbar and changes the mode of the remote so that the remote can control your source's functions.


1. Press the button for the source you want to control.
The source button glows.
2. Press .
The source powers on.
3. If the source is connected to your TV, press and select the correct input on your TV.

To stream music from your *Bluetooth*® phone or other mobile device, you must pair your mobile device with the soundbar.

Note: For more information on using *Bluetooth*® functions, refer to the owner's guide at global.Bose.com/Support/ST300

Pairing a mobile device

1. On the remote control, press and hold the *Bluetooth*® button  until the *Bluetooth*® indicator  on the soundbar blinks blue.




2. On your mobile device, turn on the *Bluetooth*® feature.
 3. Select your SoundTouch® 300 soundbar from the device list.
- Once paired, the soundbar emits a tone.

Pairing a mobile device with NFC

1. With the soundbar powered on, unlock your mobile device and turn on the *Bluetooth*® and NFC features.
2. Gently tap the NFC touchpoint on your mobile device to the top of the soundbar behind the Bose® logo.

Your mobile device may prompt you to accept pairing.



Once paired, the soundbar emits a tone.

UNIVERSAL REMOTE CONTROL DEVICE CODES

TV

888.....02250	Blue Light.....06152	Digitrex.....01808	Frigidaire.....01794
Acer.....01652	Blue Sky.....00134	Disney.....02440	Funai.....00179
Admiral.....00182	Bluesky.....00766	Dukane.....07825	Gateway.....01168
Advent.....01754	Britânia.....05900	Dumont.....00256	GE.....00027
Affinity.....06190	Broksonic.....00184	Durabrand.....02191	General Electric.....01885
Aiwa.....00406	CCE.....00160	Dynex.....03686	GFM.....04001
Akai.....00098	Celera.....01900	Electrograph.....02534	Gibraltar.....00333
America.....09172	Champion.....02647	Electrohome.....00381	Global.....02033
Amoisonic.....01027	Changhong.....01766	Electron.....01898	GoldStar.....00056
AOC.....00137	Citizen.....00046	Elektra.....01132	GPX.....01720
Apex Digital.....01550	Coby.....02056	Element.....03682	Haier.....01767
Ario.....07710	Commercial Solutions.....02427	Elite.....00274	Hallmark.....00351
Asus.....04030	Contex.....04280	Emerson.....00236	Hannspree.....03236
Atvio.....06133	Continental.....04261	Envision.....00278	H-Buster.....05926
Audiovox.....00105	Continental Electric.....09173	Epson.....02108	Helios.....02436
Auria.....04770	Coradir.....04735	Epworth.....09234	Hewlett Packard.....01671
Aventura.....02561	Craig.....00161	EQD.....05411	Himitsu.....02158
Avol.....04037	Crown Mustang.....01789	EQD Auria.....05412	Hisense.....02159
B & O.....05274	Curtis.....01897	ESA.....02420	Hitachi.....00145
Bang & Olufsen.....00118	Curtis Mathes.....00039	Fair Mate.....06083	Hitech.....01826
BGH.....03478	Cytron.....01594	Favi.....07763	Hiteker.....01595
	Daewoo.....00092	Fisher.....00154	HP.....02271
	Daytek.....02024	Fluid.....04827	Hyundai.....01206

UNIVERSAL REMOTE CONTROL DEVICE CODES

iLo.....02464	LodgingStar.....04868	New Acoustic Dimension.....05601	Planar03573
Imperial.....00387	LXI00148	NEX03694	Polaroid.....02163
InFocus.....00995	MAG03384	Nexus.....01582	Portland.....00582
Insignia.....02471	Magnavox.....00054	Nexus Electronics.....04032	Prima00586
Inteq.....00893	Magnum.....01255	Nikko.....00529	Proscan00883
iRIS.....04055	Marantz.....00128	Nimbro.....04143	Proton.....00031
IRT01830	Master-G.....02997	Noblex.....00534	Proview02133
iSymphony.....03863	Matsushita.....00478	Norcent.....01838	Pulsar.....00599
JC Penney.....05523	Maxent.....02434	Nordmende.....00537	Pyle02421
JCM04630	Megatron.....00485	NuVision.....03355	Pyle Home.....05674
Jensen.....00405	Memorex.....00037	oCOSMO.....10275	QuantumFX.....05970
JVC.....00053	MGA00155	Ölevia.....05964	Quasar.....00055
KC09223	Microsonic.....04673	Optimus.....00546	RadioShack.....00165
KDS03383	Midland.....00493	Optique.....06677	RCA.....00047
Ken Brown.....02620	Miray.....04998	Orion.....00549	Realistic.....00420
KLH.....00408	Misakai.....07712	Panasonic.....00051	Recco.....01828
Kolin.....02114	Mitsubishi Electric.....09071	Panavideo.....06623	Runco.....00632
Konka.....01235	Mitsui.....03847	Panavox.....04496	Sampo.....00032
Legend.....00940	NAD00513	PARK.....04065	Samsung.....00060
Lenoxx.....01742	Naoki.....06147	Penney.....00135	Sankey.....10257
Lexus.....06146	Naxa.....03571	Philco.....00030	Sansei.....00946
LG00511	NEC00170	Philips.....00081	Sansui.....00067
LG Alps.....01245	NetTV.....02539	Pioneer.....00166	Sanyo.....00159

UNIVERSAL REMOTE CONTROL DEVICE CODES

Sceptre.....02541	Supersonic02544	VisionQuest 04494	Arvig Communication Systems..... 05034
Scotch00855	Suzuki08893	VIZIO..... 02215	AT&T..... 00018
Scott 00309	Suzuki Time 06011	Vuon.....04421	AT&T U-verse..... 07692
Sears 00146	SVA.....01813	Wards00187	Atlantic Broadband 06171
Seiki..... 06024	Sylvania..... 00024	Waycon 01700	ATMC06389
Seiko Epson 05721	Symphonic00171	Westinghouse 02258	Axtel 09504
Semp Toshiba..... 05722	Syntax 02432	White Westinghouse..... 00830	Bell 05008
Sens 05143	SZK..... 06013	Wyse..... 02422	Bell Aliant 08093
Serie Dorada..... 02906	Tatung 00049	Xoceco.....02430	Bell ExpressVu01569
Sharp 00093	TCL 02231	Zenith 00017	Bell Fibe TV.....08078
Sigmac 05138	Technics 00250		Bevcomm 06557
Silo..... 05740	Teknika 00322		Blue Ridge Communications05037
Silo Digital 05977	Telefunken..... 00757		Bright House.....04215
Siragon..... 09109	TMK.....00736		Broadstripe05038
Soneview 09177	TNCi 01736		Buckeye Cable System05039
Sony 00000	Tonomac 03425		Cable America..... 06181
Soundesign..... 00178	Tosaki..... 06145		Cable Axion Digitel.....05027
Spectroniq..... 03385	Toshiba..... 00156		Cable Magico.....04826
Speler 08195	Upstar..... 09178		Cable One.....04216
Squareview 00706	Vidikron..... 00814		Cablecom Mexico.....06219
STI..... 06483	Vidtech..... 00815		Cablemás.....09350
SunBriteTV..... 03117	Viewsonic 01805		Cablevision.....04214
Superscan..... 02222	Viore 03579		

Cable

Access Communications 05025
Adams Cable TV.....06386
ADB.....01634
Alcatel-Lucent.....04817
Allegiance Communications 07740
Allen TV Cable 05032
Amino..... 02125
Arion 03224
Armstrong..... 00083
Arris 04776

UNIVERSAL REMOTE CONTROL DEVICE CODES

Cablevisión Argentina10396	Director01707	Inter Mountain Cable.....05053	Movistar04534
Cablevisión Mexico10395	DMT.....01749	Izzi Telecom10174	Moxi.....04777
Cablevisión Uruguay10397	Eagle Communications.....06406	Jerrold.....00003	MTA06520
Cablevision Victoria.....10383	EastLink06228	Kaon.....02465	MTS03524
Canby Telcom.....06182	Echostar.....00280	Kathrein00411	Nagravision.....04666
Cass Cable.....05040	Entone03906	LG00511	NET.....01636
CCAP.....06375	eTb08947	Liberty Cablevision.....06644	Netgem02020
CenturyLink05042	Evolution02740	Lumos Networks05062	Network Technologies.....07673
Channel Master00198	Exterity.....04429	Massillon Cable05055	NewWave Communications.....05060
Charter04213	Fidelity Communications.....05048	Matanuska Telephone Association05056	Nighthawk.....04428
ChoiceCable.....06225	Frontier Communications.....06172	Maxcom.....08543	Northland Communications.....06173
Cincinnati Bell04848	General Communications05049	Mediacom.....00482	NU Telecom.....06441
Cisco03915	General Instrument.....00329	Mediastream.....08049	Nuevo Siglo.....06089
Claro.....06221	Google.....06599	Megacable.....06217	Oi TV06031
Cogeco.....05028	Grande Communications05051	megasenal.....10376	Pace00558
Comcast.....01355	Great Plains Communications ...06180	Megaseñal.....10323	Panasonic00051
Comporium05046	GTD Manquehue.....09274	MetroCast Cablevision05057	Paul Bunyan Communications...06179
Consolidated Communications05047	Guest-Tek.....03391	Mi-Connection.....06431	Philips00081
Convenient10324	Handan.....02765	Midcontinent Communications05059	Pico Digital10066
Coship02364	Hawaiian Telcom06917	Mid-Hudson Cable05058	Pioneer00166
Cox04212	Huawei04700	Minerva Networks.....04898	Pioneer Telephone.....05064
Digeo01678	Humax01200	Motorola00504	Pirelli03601
	Intek.....01212		Playcom10379

UNIVERSAL REMOTE CONTROL DEVICE CODES

Prime.....03964	Technotrend.....02228	Wegener.....03821	Bell Satellite TV.....08079
RCN.....04377	TeleCable.....04498	WEHCO Video.....06174	brite-View.....04520
Reach Broadband.....07118	Telecentro.....06223	Westman Communications.....05030	Century.....00197
Rogers.....04314	Telefonica.....02406	WideOpenWest.....04436	Claro.....06221
Sagem.....01386	Telmex.....06220	Windjammer Cable.....06178	Coship.....02364
Sagemcom.....04858	Telsur.....09895	WNC.....04895	Digital Tech.....06203
Samsung.....00060	TELUS.....04962	WOW!.....08179	Digiwave.....03232
SaskTel.....02178	Thomson.....00771	Xavi.....09594	DirecTV.....01988
Schurz Communications.....09932	Time Warner.....03602	Xfinity.....08096	Dish Mexico.....06215
Scientific Atlanta.....00008	TiVo.....01492	Zito Media.....06177	Dish Network.....01989
Service Electric.....05066	Totalplay.....09859	ZTE.....04702	Dishpro.....01785
Shaw.....04315	Transparent Video Systems.....04387	Z-Trak.....04474	Echostar.....00280
Shaw Direct.....04816	TRC.....07667	ZyXEL.....03770	Elsys.....06185
Shentel.....05067	TV Cable.....06224		Embratel.....04577
Skyworth.....01424	TVS Cable.....07656		Entel.....09510
Source Cable.....05029	UNE.....08299		Freesat.....01164
Suddenlink.....04217	U-verse.....07693		Frontier Communications.....06172
SuiteLinq.....05182	Verizon.....01576		General Instrument.....00329
Supercanal.....06222	Vidéotron.....05992		GOI.....01704
Tbaytel.....07650	Vivo.....04204		Gold Box.....01176
TCC.....03575	VTR.....04965		Gradiente.....00338
TDS.....07482	Wave Broadband.....05070		GVT.....07774
Technicolor.....04758	Wavevision.....07664		Handan.....02765

Satellite

Aquário.....06186
Arion.....03224
Arris.....04776
AZ America.....05128
AZBox.....03684
Bell.....05008
Bell ExpressVu.....01569

UNIVERSAL REMOTE CONTROL DEVICE CODES

HTS.....	00682	Odobo	07984	Tele Red	04721	Apex Digital.....	01550
Huawei	04700	Oi TV.....	06031	Telefonica.....	02406	Asahi.....	04331
Hughes Network Systems.....	00791	Omegasat.....	01319	Televisa.....	01481	Audio Authority.....	01689
Humax	01200	Openbox.....	03505	TELUS.....	04962	Audiovox	00105
i-Link.....	04852	OrbiSat.....	06201	Thomson.....	00771	B & O.....	05274
Indovision.....	01210	Pace	00558	TiVo	01492	Bang & Olufsen.....	00118
Innova.....	01211	Philips.....	00081	TuVes	09508	BBK	01055
Intv	09122	RCA	00047	TVA Digital.....	03525	Bel Canto Design.....	02202
ISkyB.....	01219	Sagem	01386	UEC	02136	Blaupunkt.....	00133
Jerrold.....	00003	Sagemcom.....	04858	UNE.....	08299	Blue Parade.....	01710
JVC.....	00053	Samsung.....	00060	Via Embratel.....	04578	Broksonic.....	00184
Kaon.....	02465	SatHawk.....	04892	Vivo	04204	BuBuGao	02398
Kathrein	00411	Shaw Direct.....	04816	Zenith	00017	California Audio Labs.....	00173
Lava.....	02528	Sky Brasil	07861	Zinwell.....	01994	Cambridge Audio.....	02145
Lemon	01242	Sky Mexico	04322			CineVision	01841
LG	00511	SMT	05104			Citizen	00046
Motorola	00504	Solomend.....	04893			Coby.....	02056
Movistar	04534	Sonicview	03993	Accurian.....	02575	Cougar.....	06004
Nagra.....	03143	Star.....	01439	Akai	00098	Curtis	01897
Netgem	02020	Star Choice.....	00950	Allegro.....	00311	Curtis Mathes	00039
Netsat.....	01302	Supernova	01694	Amvox	08726	Daewoo.....	00092
Next Level	00943	Technicolor.....	04758	Anthem	01031	Days	08712
Norsat.....	00538	Technotrend	02228	Anthem Statement	05250	Denon.....	00246

DVD

Accurian.....	02575
Akai	00098
Allegro.....	00311
Amvox	08726
Anthem	01031
Anthem Statement	05250
Apex Digital.....	01550
Asahi.....	04331
Audio Authority.....	01689
Audiovox	00105
B & O.....	05274
Bang & Olufsen.....	00118
BBK	01055
Bel Canto Design.....	02202
Blaupunkt.....	00133
Blue Parade.....	01710
Broksonic.....	00184
BuBuGao	02398
California Audio Labs.....	00173
Cambridge Audio.....	02145
CineVision	01841
Citizen	00046
Coby.....	02056
Cougar.....	06004
Curtis	01897
Curtis Mathes	00039
Daewoo.....	00092
Days	08712
Denon.....	00246

UNIVERSAL REMOTE CONTROL DEVICE CODES

Digix.....02441	Insignia.....02471	Onkyo.....00102	Sharp.....00093
Diplomat.....08683	Integra.....01842	Oppo.....02634	Sherwood.....00180
Directed Video.....03680	Irradio.....01217	Panasonic.....00051	Shinsonic.....01769
Disney.....02440	JBL.....00399	Philco.....00030	Sonic Blue.....01715
Durabrand.....02191	JVC.....00053	Philips.....00081	Sony.....00000
Dynex.....03686	Kenwood.....00417	Pioneer.....00166	Suzuki.....08893
Emerson.....00236	KLH.....00408	Polk Audio.....00647	Suzuki Time.....06011
Funai.....00179	Konik.....08686	Presidian.....03093	SV2000.....07875
GE.....00027	Lenoxx.....01742	Proceed.....01606	Sylvania.....00024
General Electric.....01885	LG.....00511	Proscan.....00883	Symphonic.....00171
GFM.....04001	Logitech.....01655	RCA.....00047	SZK.....06013
Go Video.....00334	Magnavox.....00054	RE-BL.....04625	TCL.....02231
GoldStar.....00056	Marantz.....00128	Recco.....01828	Technics.....00250
GPX.....01720	McIntosh.....00480	Rio.....01837	Theta Digital.....00770
Gradiente.....00338	Memorex.....00037	Rotel.....00630	Toshiba.....00156
Greenhill.....01692	Microsoft.....01756	Sampo.....00032	Tronics.....08510
Grundig.....00345	Mintek.....01788	Samsung.....00060	TruTech.....03444
Harman/Kardon.....00356	NAD.....00513	Sansui.....00067	Urban Concepts.....01695
Hitachi.....00145	Naxa.....03571	Sanyo.....00159	Viore.....03579
Hitech.....01826	Nesa.....01787	Schneider.....00665	VisionQuest.....04494
Hiteker.....01595	New Acoustic Dimension.....05601	Seiki.....06024	VIZIO.....02215
Initial.....02017	Nyko.....03830	Semp.....00949	Vtrek.....01893
Inovox.....08296	Ölevia.....05964	Semp Toshiba.....05722	WB Electronics.....04626

UNIVERSAL REMOTE CONTROL DEVICE CODES

Xbox.....01840	Integra.....01842	QED.....00884	Alienware02082
Yamaha00019	Kenwood00417	Quad.....00601	CyberPower02083
Zenith00017	Krell.....00860	Quasar.....00055	Dell.....02064
	Linn.....00437	RCA.....00047	DirecTV.....01988
	Magnavox.....00054	Realistic.....00420	Gateway.....01168
	Marantz.....00128	Rotel.....00630	Hewlett Packard01671
	Matsui.....00477	SAE.....00633	Howard Computers02272
	MCS.....00456	Sansui.....00067	HP.....02271
	Miro.....01693	Sonic Frontiers.....01431	Humax.....01200
	Mission.....00499	Sony.....00000	Hush.....02499
	MTC.....00185	Sylvania.....00024	iBUYPOWER.....02090
	Myryad.....01104	TAG McLaren.....01800	Linksys.....02151
	NSM.....00516	TAG McLaren Audio.....05784	Media Center PC.....02084
	Onkyo.....00102	Tascam.....00743	Microsoft.....01756
	Optimus.....00546	Teac.....00041	Mind.....02085
	Panasonic.....00051	Technics.....00250	NiveusMedia.....06523
	Parasound.....00566	Wards.....00187	Northgate.....02086
	Philips.....00081	Yamaha.....00019	Philips.....00081
	Pioneer.....00166	Zonda.....00846	RCN.....04377
	Polk Audio.....00647		Ricavision.....02507
	Primare.....02008		Sony.....00000
	Proceed.....01606		Stack 9.....02509
	Proton.....00031		Systemax.....02274

CD

Aiwa.....00406
Arcam.....00077
Burmester.....00869
California Audio Labs.....00173
Carver.....00191
CCE.....00160
Curtis Mathes.....00039
Denon.....00246
DKK.....00872
DMX Electronics.....01697
Epworth.....09234
Garrard.....00326
Genexxa.....00330
Harman/Kardon.....00356
Hitachi.....00145
Inkel.....00391
Insignia.....02471

VCR

ABS.....02081

UNIVERSAL REMOTE CONTROL DEVICE CODES

Tagar Systems.....	02087	Olive.....	03342	Auralic.....	10122	Kaleidescape.....	03215
TiVo.....	01492	Philips.....	00081	Boxee.....	04583	LaCie.....	03201
Toshiba.....	00156	Polk Audio.....	00647	Buffalo.....	03032	LG.....	00511
Touch.....	02088	Pro-Ject.....	04641	Ceton.....	08542	Linksys.....	02151
Viewsonic.....	01805	Pro-Ject Audio Systems.....	05669	Channel Master.....	00198	Logitech.....	01655
Voodoo.....	02513	Scandyna.....	04027	CyberPower.....	02083	Magnavox.....	00054
ZT Group.....	02089	Sonance.....	03244	Dell.....	02064	Matricom.....	08008

Audio Accessory

Apple.....	02414
Audyssey.....	06131
Denon.....	00246
DLO.....	03211
i.Sound.....	06510
iHome.....	03595
iLive.....	03357
Insighia.....	02471
iPort.....	03031
Jamo.....	02199
Klipsch.....	02005
Logitech.....	01655
Memorex.....	00037


Video Accessory

A.C.Ryan.....	04453
ABS.....	02081
AL Tech.....	03216
Alienware.....	02082
Amlogic.....	04694
Apple.....	02414
Aquário.....	06186
Armada.....	10289
Asus.....	04030
Asustor.....	09767

Funai.....	00179	Ematic.....	10173	Media Center PC.....	02084
Gateway.....	01168	D-Link.....	02454	MediaGate.....	03627
G-Box Midnight.....	09331	DVICO.....	02607	Mediasonic.....	03433
Hewlett Packard.....	01671	Ematic.....	10173	Mi.....	08185
HomeWorx.....	08348	Funai.....	00179	Micca.....	06593
Howard Computers.....	02272	Gateway.....	01168	Microsoft.....	01756
HP.....	02271	G-Box Midnight.....	09331	Mind.....	02085
Hush.....	02499	Hewlett Packard.....	01671	Minix.....	02198
iBUYPOWER.....	02090	HomeWorx.....	08348	Netgear.....	02574
Incredisonic.....	10177	Howard Computers.....	02272	NiveusMedia.....	06523
Inkel.....	00391	HP.....	02271	Northgate.....	02086
lomega.....	03872	Hush.....	02499	nSTREAMS.....	02013
iView.....	04734	iBUYPOWER.....	02090	NVIDIA.....	10288
		Incredisonic.....	10177	Omniverse.....	09341
		Inkel.....	00391	Ortek.....	09254
		lomega.....	03872	Panasonic.....	00051

UNIVERSAL REMOTE CONTROL DEVICE CODES

Patriot.....	01338	Xtreamer.....	04420
Pivos.....	09120	Yamaha.....	00019
Popcorn Hour.....	03862	ZT Group.....	02089
PrimeDTV.....	04828	Zune.....	04530
RCA.....	00047		
Ricavision.....	02507		
Roku.....	02457		
Seagate.....	04466		
Sherwood.....	00180		
Sling Media.....	04273		
Sony.....	00000		
Stack 9.....	02509		
Systemax.....	02274		
Tagar Systems.....	02087		
Toshiba.....	00156		
Touch.....	02088		
TViX.....	04223		
Viewsonic.....	01805		
VIZIO.....	02215		
Voodoo.....	02513		
Western Digital.....	04168		
Xbox.....	01840		
Xiaomi.....	08184		



774092-0010

BOSE[®]
Better sound through research[®]

©2016 Bose Corporation, The Mountain,
Framingham, MA 01701-9168 USA
AM774092 Rev. 00